


# U Awesome some



U Awesome  
Selection



U4H-NH1-M21B57-73A-R2  
PRESIDENTIAL HIGH BACK  
SYNCHRON CHAIR

H 1170-1270  
W 635  
D 640  
SH 430-530  
SW 490  
SD 485  
BW 660

U4M-NH1-M21B57-73A-R2  
MANAGERIAL MID BACK  
SYNCHRON CHAIR

H 1030-1130  
W 635  
D 640  
SH 430-530  
SW 490  
SD 485  
BW 660

U4M-NH1-M21B57-40A-R2  
MANAGERIAL MID BACK  
SYNCHRON CHAIR

H 1030-1130  
W 610  
D 640  
SH 430-530  
SW 490  
SD 485  
BW 660

U4M-PB2-M21B57-40A-R1  
MANAGERIAL MID BACK  
SYNCHRON CHAIR

H 1025-1125  
W 610  
D 620  
SH 425-525  
SW 490  
SD 485  
BW 630

U4V-CE42-B58-40A  
VISITOR MID BACK CHAIR

H 1040  
W 610  
D 610  
SH 460  
SW 490  
SD 485  
BW 485

\*All Dimension in mm

W : Overall Width  
D : Overall Depth  
H : Overall Height

SW : Seat Width  
SD : Seat Depth  
SH : Seat Height  
BW : Base Width

Our products are manufactured under stringent quality controls and is recipient of ISO 9001:2000 quality assurance.

With the constant upgrading of products, PERFECT U reserves the right to make appropriate changes of specification without any prior notice.

U Awesome  
Selection



## Recliner Synchron Mechanism(M21B57)

### 1 Seat Height Adjustment

- Lift right-hand lever up to adjust the seat height without sitting on the chair.
- To lower seat height, lift right-hand lever up while seated.
- For optimal posture, thighs should be parallel with the ground and both feet flat on the floor. This improves blood circulation and comfort.

### 2 Seat Position Locking-recliner Synchron Mechanism.

- Push in the right hand lever to lock the seat position.
- Pull outwards the lever to unlock.
- The mechanism provides dynamic seating which maintains support as you move and recline.

### 3 Tension Control

- Turn tension control clockwise for a more rigid back tilt and anti clockwise for a softer tension to suit control according to body weight.
- The tension control allows comfortable and relaxed seating according to body weight.

### 4 Headrest

- With height and angle adjustment that provide ergonomic support for the neck to prevent cervical strains.

### 5 Adjustable Armrest (73A)

- Height adjustment armrest with PU padding on top to provide comfortable resting position for the arms.

### 6 Fixed Armrest (40A)

- Modern design PP injection fixed T-Armrest to provide a natural resting position for the arms.

### 7 NH1 BASE + R2 ROLLER

- Sleek nylon high base NH1 with R2 60mm roller.

### 8 PB2 BASE + R1 ROLLER

- The PP chair base PB2 with R1 heavy duty nylon castor.
- Maximum tolerance loading of this chair is 100kg.

### 9 CE42 Base

- Epoxy Black Sledge Base.



### 9 CE42 Base

- Epoxy Black Sledge Base.



AWESOME  
"Creating a Perfect Balance"



OASIS FURNITURE  
INDUSTRIES SDN. BHD.

No. 2 & 3, Jln Perindustrian Gemilang, Tmn Perindustrian Gemilang,  
Batu 4, Jin Mersing, 86000 Kluang, Johor, Malaysia.  
Tel : (+6) 07-7733 292 | Fax : (+6) 07-7739 181  
Email : ralphgrp@tm.net.my | Website : www.perfect-u.com.my

